

Wearable electrochemical biosensors for monitoring performance athletes

19/08/11





Wearable electrochemical biosensors for monitoring performance athletes

19/08/11



@ cyrusmekon
#Berkeley



Contents



- The need for wearable sensors.
- Wearable electrochemical sensors.
- Diverse material for sensing platforms.
 - Ionic Liquids
- Electrochemical biosensing: The road ahead.
 - Ionogels
- Conclusions.



National Centre for Sensor Research



- Over 260 f/t researchers and support staff
- 23 affiliated faculty
- Investments and income since 1999 now approaching €100 million
- 1500 m² well-equipped specialist lab space and offices
- Phase II expansion completed 2008 (1300 m²)





The Centre for Sensor Web Technologies















National Centre for Sensor Research



- Over 260 f/t researchers and support staff
- 23 affiliated faculty
- Investments and income since 1999 now approaching €100 million
- 1500 m² well-equipped specialist lab space and offices
- Phase II expansion completed 2008 (1300 m²)

CLARITY



The Centre for Sensor Web Technologies
















CLARITY – SFI CSET



Vision: Sensing Mind, Body & Place



- 5-year, €16.4 million research program to develop next generation Sensor Web Technologies with significant environmental focus
- Brings together fundamental materials science, functional polymers, device prototyping, energy management, adaptive middleware, wearable sensors, distributed environmental monitoring.






CLARITY – SFI CSET



Vision: Sensing Mind, Body & Place



- 5-year, €16.4 million research program to develop next generation Sensor Web Technologies with significant environmental focus
- Brings together fundamental materials science, functional polymers, device prototyping, energy management, adaptive middleware, wearable sensors, distributed environmental monitoring.







- Wearable sensors allow the continuous monitoring of a person's physiology in a natural setting.
- Health-monitoring systems using electronic textiles are mainly targeting applications based upon physiological parameter measurements, such as body movements or electrocardiography (ECG).
- However, due to their relative complexity, there is very little activity in the development of real-time wearable chemo/bio sensing for sports applications.





- Micro-Total-Analysis-Systems and Lab-on-a-Chip technology are widely used in analytical chemistry and biotechnology^[1] but are still rarely used in other areas like sports science.
- In this field, wearable sensors are becoming increasingly employed, through the use of embedded transducers or smart fabrics for monitoring parameters like breathing rate, heart rate and footfall.
- These sensors require that the desired sample of analysis, usually a body fluid such as sweat is delivered to the sensor's active surface, whereupon a reaction happens and a signal is generated.



[1] K.-i. Ohno, K. Tachikawa and A. Manz, ELECTROPHORESIS, 2008, 29, 4443-4453.

[2] D. Diamond, S. Coyle, S. Scarmagnani and J. Hayes, Chem. Rev., 2008, 108, 652-679.

[3] P. Bhandari, T. Narahari and D. Dendukuri, *Lab on a Chip*, 2011, **11**, 2493-2499.





- Moreover the system must be low cost, while still being robust, miniature, flexible, washable, reusable or disposable[2].
- All these requirements point to micro-fluidic devices as the key tools for improving wearable chemo-/bio-sensing[3].

• To open a dramatically wider field of applications, chemical measurements on body fluids (blood, sweat, saliva and urine) are needed.





[2] D. Diamond, S. Coyle, S. Scarmagnani and J. Hayes, Chem. Rev., 2008, 108, 652-679.


[3] P. Bhandari, T. Narahari and D. Dendukuri, Lab on a Chip, 2011, 11, 2493-2499.





Med-Tech Innovation

Design



Mid-tech Innovation May - June 2011



Remote Sensing and the

AGEING POPULATION

A research group at Dublin City University headed by Professor Dermot Diamond is investigating technologies that will provide new monitoring services in the home.





- This area of research is unfortunately still poorly developed due to the difficulty in sampling such fluids. The BIOTEX project tackled some of these problems by developing a textile-based system to collect and analyze sweat by using a textile-based sensor capable of performing chemical measurements^[2].
- The great advantage of analyzing sweat for health monitoring is that it is noninvasive, reasonably accessible, with the potential to provide valuable physiological information^[4].
- However, advances in this direction have been limited due to the difficulty in obtaining uncontaminated samples.



[2] D. Diamond, S. Coyle, S. Scarmagnani and J. Hayes, Chem. Rev., 2008, 108, 652-679.

[4] J. Massie, K. Gaskin, P. V. Asperen and B. Wilcken, Pediatric Pulmonology, 2000, 29, 452-456.



Wearable Electrochemical Sensors



- Wearable sensors ideally should have the ability to monitor the physiology of the wearer and the surrounding environment.
- Wearable sensor may respond to physical changes, such as body temperature or movements of the joints.
- A chemical sensor (chemosensor) detects and measures a particular chemical in its environment.
- Biosensors are closely related to chemical sensors, distinguished by the molecular recognition element which is biological in nature (e.g. enzyme, receptor, DNA, antibody, or microorganism)[5]



U I



PHYSICAL SENSORS

Breath rate, heart rate, activity, posture, skin temperature...







PHYSICAL SENSORS

Breath rate, heart rate, activity, posture, skin temperature...

TRAINTRAKTM
heart rate, respiration rate, posture, activity, and GPS location







NIKE-APPLE iPOD SPORTS KIT






Scosche myTrek sends workout vitals to your iPhone, starts shipping now for \$130 (video)

By Zach Honig Dosted Aug 9th 2011 9:40PM



The myTREK utilizes two LEDs combined with a photo sensor to detect minute changes in the user's blood pressure to accurately measure pulse. A built-in accelerometer allows the myTREK to adjust for movement during exercise from the user's heartbeat allowing for an extremely accurate measurement of pulse and calories burned.





John Rogers @ University of Illinois
11/08/2011

Ultra-thin, self-adhesive electronics device that can effectively measure data about the human heart, brain waves and muscle activity--all without the use of bulky equipment, conductive fluids or glues.



Link: http://www.nsf.gov/news/news_summ.jsp?cntn_id=121343&org=NSF&from=news

Wearable electrochemical Sensors





Wearable electrochemical Sensors



Why sweat?

- The great advantage of analyzing sweat for health monitoring is that it is noninvasive, easily accessible, and it offers valuable physiological information
- The sweat test previously used for the diagnosis of cystic fibrosis (CF)
- This is a once-off test that is performed in newborns and the diagnosis is based on sodium and chloride concentration levels.






- BIOTEX was an EU-funded project that aimed to develop textile sensors to measure physiological parameters and the chemical composition of body fluids, with a particular interest in sweat.
- Wearable sensing system had been developed that integrates a textile-based fluid handling system for sample collection and transport with a number of sensors including sodium, conductivity, and pH sensors.
- It was possible to monitor a number of physiological parameters together with sweat composition in real time.










• Multiparametric patch containing pH indicator, conductivity, sodium, and temperature sensors.



ONCSR













• The textile pump has been designed in such a way that it can successfully collect sweat from human subjects during exercise.



• Sweat is analyzed by pH, sodium, and conductivity sensors and stores the sample in an absorbent in such a way as to allow for a continuous flow of fresh sweat.

• The ability to measure changes in sweat electrolyte concentrations can assist people in choosing the correct level of hydration and avoid the need for medical intervention.







• The textile pump has been designed in such a way that it can successfully collect sweat from human subjects during exercise.



• Sweat is analyzed by pH, sodium, and conductivity sensors and stores the sample in an absorbent in such a way as to allow for a continuous flow of fresh sweat.







In-house UV Sensor









In-house UV Sensor





2 hrs Sicily









In-house UV Sensor









Dublin


















NASA: Wearable sensor patches



Abbot Freestyle Navigator



PharmChek Sweat Patch








For the Postgrads








For the Postgrads









What is an Ionic Liquid (IL)?

• According to current convention, a salt melting below the normal boiling point of water is known as an "ionic liquid"





What is an Ionic Liquid (IL)?

- According to current convention, a salt melting below the normal boiling point of water is known as an "ionic liquid"
- The first IL was reported almost a century ago by Walden^[7], who protonated ethylamine with nitric acid to yield ethylammonium nitrate

[7] P. Walden, Bull. Acad. Sci. St. Petersburg, 1914, 405.





What is an Ionic Liquid (IL)?

- According to current convention, a salt melting below the normal boiling point of water is known as an "ionic liquid"
- The first IL was reported almost a century ago by Walden^[7], who protonated ethylamine with nitric acid to yield ethylammonium nitrate
- The number of potential anion-cation combinations available reputedly equate to one trillion (10^{12}) different ILs^[8]

[7] P. Walden, Bull. Acad. Sci. St. Petersburg, 1914, 405.


[8] R. D. Rogers and K. R. Seddon, Ionic Liquids as Green Solvents: Progress and Prospects,

American Chemical Soceity, 2003.






What is an Ionic Liquid (IL)?








What is an Ionic Liquid (IL)?




Typical ions to form ionic liquids



Hydrophilic Tg -81°C only Hydrophobic M.P. of 6.4°C










Generation 1: ILs with unique tunable physical properties

Physical property





Physical property






[9] W. L. Hough, M. Smiglak, H. Rodriguez, R. P. Swatloski, S. K. Spear, D. T. Daly, J. Pernak, J. E. Grisel, R. D. Carliss, M. D. Soutullo, J. H. Davis and R. D. Rogers, New J. Chem., 2007, 31, 1429-1436.








Generation 2:

ILs with targeted chemical properties combined with chosen physical properties

Chemical property




Chemical property



[9] W. L. Hough, M. Smiglak, H. Rodriguez, R. P. Swatloski, S. K. Spear, D. T. Daly, J. Pernak, J. E. Grisel, R. D. Carliss, M. D. Soutullo, J. H. Davis and R. D. Rogers, New J. Chem., 2007, 31, 1429-1436.









Generation 3:

ILs with targeted biological properties combined with chosen physical and chemical properties

Biological property



Biological property





[9] W. L. Hough, M. Smiglak, H. Rodriguez, R. P. Swatloski, S. K. Spear, D. T. Daly, J. Pernak, J. E. Grisel, R. D. Carliss, M. D. Soutullo, J. H. Davis and R. D. Rogers, New J. Chem., 2007, 31, 1429-1436.




lower melting, antibacterial / NSAID




Subsets of ILs

• Phosphonium based ILs



• Bio compatible ILs








• Cytec^R routinely produces tetraalkylphosphonium halides such as the ionic liquid trihexyl-tetradecyl phosphonium chloride

• Phosphonium based ILs








Phosphonium based ILs

• Cytec^R routinely produces tetraalkylphosphonium halides such as the ionic liquid trihexyl-tetradecyl phosphonium chloride




- Phosphonium ILs offer, in some cases, several advantages over other types of ILs, including, higher thermal stability, lower viscosity, and higher stability in strongly basic or strongly reducing conditions.
- Historically these compounds have been used as biocides^[10] and phase transfer catalysts^[11]

[10] D. Jerchel, *Chem. Ber.*, 1943, **76B**, 600.
[11] A. W. Herriott and D. Picker, *J. Am. Chem. Soc*, 1975, **97**, 2345.






• Phosphonium based ILs



$$\begin{array}{c|c}
\ominus & C_{14}H_{29} \\
CI & + P & C_{6}H_{13} \\
\hline
C_{6}H_{13} & C_{6}H_{13}
\end{array}$$


Trihexyl-tetradecyl phosphonium chloride,

Liquid at room temperature



Tetrabutyl phosphonium chloride

M.P 67 °C



Tetraoctyl phosphonium bromide

M.P 45 °C





Excellent Review



K. J. Fraser and D. R. MacFarlane, *Aust. J. Chem.*, 2009, **62**, 309-321.

Phosphonium-Based Ionic Liquids: An Overview

Kevin J. Traser^A and Douglas R. MacFarlane^{A,S}

*School of Chemistry, Monash University, Wellington, VIC 3800, Australia.

⁶Corresponding author. Email: Douglas. Mactarlane thici morush.edu.au

Phosphonium cution-based ionic liquids (ILA) are a reality available family of ILA that in some applications offer superior properties as compared to nitrogen cution-based ILA. Applications recently investigated include their use as extraction solvents, themself synthesis solvents, electrolytes in batteries and super-sepacions, and in corrosion procession. As the same time the range of cution—axion combinations available commercially has also been increasing in recent year. Here we provide an overview of the properties of these intervening materials and the applications in which they are appearing.

Manuscript received: 19 December 2008. Final version: 9 March 2009.

Introduction

According to current convention, a salt that melts below the normal beiling point of water is known as an 'tomic liquid' (EL) or by one of many synonyms including low/ambient/soom temperature motion salt, lowic fluid, liquid organic salt, flued salt, and neonetic solvens. (1) The variation in properties between salts, even those with a common cation but different unions, is dramatic. For example, bars/metry/insidace/sum becaffusesphosphate (Camin(EFs)) is immiscible with water, whereas buyimely/iniduolium tetrafuoroborate [Canin][BFa] is water soluble.[2] This sort of variation in physical properties gave rise to Seddow's description of ILs as 'designer selvents'. The number of potential anion-cation combinations possible reputedly equates to one trillion (10⁽¹⁾) different ILs. ILs have received much attention of late because of their potential application in green chemistry and as novel electrochemical materials. They have indeed become 'designer selvenos', with musty ILs now being designed for a specific application. For example as potential electrolyses for section electrochemical devices, ^{1-|x|} including rechargeable lithium cells, ^{1-|x|} solar cells, ^{1-|x|} actuators, ^{1-|x|} and devite layer expection, ^{1-|x|}

Nitrogen-based carious, in particular N-methylimidasolium and pyrrolidinium salts, have been the subject of many of the publications in the field. A number of phosphonium cation-based ILs are also available and have a range of useful properties, but have been much low studied. Early reports regarding phosphonium ILs were published in the 1970s by Punhall using stansate and germanate salid ²⁴⁻³⁷ and by Katilon et al. ²⁴⁻⁴⁷ in the 1980s centering on the use of molten totrabuty/phosphonium beomide as an ionic solvent. To some extent the slower uptake of work on phosphonium ILs can be attributed to the difficulty in symbostring the starting materials, for example inhut/phosphine. Although phosphine derivatives have been available on a commercial scale since 1971, it was not used 1990 that inbuty/phosphine became available on a large scale. [41] Since then tetrahurylphosphosium chloride and bromide have become widely available on a multi-ton scale, along with many other trially/phosphines and their corresponding quaternary phosphonium salts, in particular from Cytec Industries Inc. [41]

Variation of the four substituents on the phosphonium cation, along with the multisude of metalolic anions, represents an enoneous number of possible sales. Those commercially available as of November 2008, for example, can be found in Table 1.



Kents J. France received his M.Sr. in 2004 from the University of therefore, Scotland. The recently completed his Ph.D. under the approximate of Professor D. B. Martinane entitled "Physicial Properties of Phosphosium Based lattic Unjude" or Managle University, Medicanae. Microsoft international are electronic for non-pile of the and note injude-based chamical insures.




Professor Dong Martfullare leads the Manach Innic Liquids Group at Minach University. Bit is also the program houter of the Energy Program is the functional Contrary for Electromaterials, Science, of the case in PLS graduates of Professor 1992, and the production of Manach Chairwist, Professor Martfulnas was recently awarded an Assemblan Research Contact Production Politically in cased his work on Political Martfulnas was recently awarded an Assemblan Research Contact Production Politically in Control Industrial Political Political Industrials and Science of Political P





Bio compatible ILs




- In an attempt to steer away from fluorous anions, a communication by Carter et al.^[13] opened up a new field in the Ionic liquid world.
- The use of common sweeteners such as saccharin and acesulfamate were used in the formation of new ionic liquids.^[13]
- These anions, in their alkali metal salt form, are widely used in foodstuffs and non-nutritive sweeteners




[13] E. B. Carter, S. L. Culver, P. A. Fox, R. D. Goode, I. Ntai, M. D. Tickell, R. K. Traylor, N. W. Hoffman and J. H. Davis, Jr., *Chem. Comm.*, 2004, 630.













After which:

Micro filters, activated Carbon, alumina column







Dry Acetone 24 Hrs

C₆H₁₃

C₆H₁₃


O

NaCl

After which:

Micro filters, activated Carbon, alumina column











6 new ILs.





Purchased ILs






Thermal Properties

IL	Tg /°C	T _{dec} / oC
[P6.6.6.14][Sacc]	-56	197
[P6,6,6,14][Ace]	-61*	196
[P _{6,6,6,14}][Cyc]	-53	194
[P6.6.6.14][NTf2]**	-76	400
[P _{6,6,6,14}][dca]**	-67	395
[P _{6,6,6,14}][C1]	-61	373
[P _{4,4,4,4}][Sacc]	-34	300
[P _{4,4,4,4}][Ace]	-47 (T_g) 5 (crystallisation) 42 (melt, $\overline{\Delta}S_f = 43(10) \text{ JK}^{-1}\text{mol}^{-1}$)	280
[P _{4,4,4,4}][Cyc]	-32	280
[N _{1,8,8,8}][Cl]		202
[N _{8,8,8,8}][CI]	33 ($S_{III} - S_{II} \overline{\Delta} S_f = 12(10) \text{ JK}^{-1} \text{mol}^{-1}$) 44 ($S_{II} - S_I \overline{\Delta} S_f = 68(10) \text{ JK}^{-1} \text{mol}^{-1}$) 54 ($\underline{T}_{melt} \overline{\Delta} S_f = 59(10) \text{ JK}^{-1} \text{mol}^{-1}$)	196





Density








Transport

IL	Conductivity (S cm ⁻¹) (40 °C)	Viscosity (Pa.s) (40 °C)
[P _{6,6,6,14}][C1]	9.5 x 10 ⁻⁶	0.70
[P _{6,6,6,14}][Cyc]	8.9 x 10 ⁻⁶	0.62
[P _{6,6,6,14}][dbsa]	6.7 x 10 ⁻⁶	0.95
[P6.6.6.14][Ace]	6.4 x 10 ⁻⁵	0.67
[P _{6,6,6,14}][Sacc]	3.0 x 10 ⁻⁵	0.58
$[P_{6,6,6,1d}][NTf_2]$	1.8 x 10 ⁻⁴	0.15
[P6.6.6.14][dca]	3.8 x 10 ⁻⁴	0.12
[P4,4,4,4][Sacc]	4.0 x 10 ⁻⁵	1.58
[P _{4,4,4,4}][Ace]*	1.5 x 10 ⁻⁴	
[P _{4,4,4,4}][Cyc]*	8.7 x 10 ⁻⁵	
$[N_{I,8,8,8}][Cl]$	5.4 x 10 ⁻⁵	0.57
[N _{8,8,8,8}][Cl]**	1.2 x 10 ⁻⁸	The State of






Conductivity














Viscosity







- "How ionic is my ionic liquid" has become a question increasingly posed by scientists in the literature.
- To probe ion-ion interactions and "assess" the ionicity of ILs, test cases comprised of phosphonium cations paired with chloride or N-acyl-N-sulfonyl anions were prepared.







ChemComm





[14] K. J. Fraser, E. I. Izgorodina, M. Forsyth, J. L. Scott and D. R. MacFarlane, Chem. Commun., 2007, 3817-3819.





ChemComm



ChemComm





[14] K. J. Fraser, E. I. Izgorodina, M. Forsyth, J. L. Scott and D. R. MacFarlane, Chem. Commun., 2007, 3817-3819.





• Ionic liquids (ILs) have evolved as a new type of non-aqueous solvents for biocatalysis, mainly due to their unique and tunable physical properties [15]

Factors that affect Enzyme activity in ILs







• Ionic liquids (ILs) have evolved as a new type of non-aqueous solvents for biocatalysis, mainly due to their unique and tunable physical properties [15]

Factors that affect Enzyme activity in ILs

IL polarity

Hydrogen bonding bascicity

Viscosity

Ion kosmotropicity


Enzyme dissolution









Through smart design enzyme stability can be greatly enhanced



PBS







[16] K. Fujita, D. R. MacFarlane and M. Forsyth, Chem. Commun., 2005, 4804-4806.




Through smart design enzyme stability can be greatly enhanced


- Enhanced solubility of cytochrome c.
- dhp anion provided both a proton activity similar to that in neutral water as well as hydrogen bonding donor and acceptor sites.
- Choline DHP should enzyme stability up to 130 oC



ONCSR National Centre for Service Research

Ideas Tree for Ionic liquids







- Point-of-care (POC) glucose biosensors play an important role in the management of blood sugar levels in patients with diabetes.
- One of the most commonly used enzymes in glucose biosensors is Glucose Oxidase (GOx).
- Amperometric biosensors employing IL's have been reported previously, for example, ([C₄mIm][BF₄]) has been used as a mediator in a electrochemical H₂O₂ biosensor^[17].



[17] Y. Liu, M. Wang, J. Li, Z. Li, P. He, H. Liu and J. Li, *Chem. Commun.*, 2005, 1778-1780.





- This work investigates colorimetric and electrochemical methods of glucose detection by combining the enzyme's specificity, with the unique characteristics of IL's and either a chromogen (o-Dianisidine) or electrochemical mediator (ferrocene) to enhance the detection.
- This interest is driven by the need to find molecular environments in which enzymes are highly stabilized while retaining redox activity.



[17] Y. Liu, M. Wang, J. Li, Z. Li, P. He, H. Liu and J. Li, *Chem. Commun.*, 2005, 1778-1780.





• Ionic liquids used in this study include $[C_2mIm][EtSO_4]$, $[P_{6,6,6,14}][Cl]$, $[P_{6,6,6,14}][dca]$ and $[P_{6,6,6,14}][NTf_2]$





- An alternative working electrode
- Carbon Cloth- Graphitized Spun Yarn Carbon Fabrics


• Fabric tailor-ability results from controlling the yield on rovings and yarns, and allows for a variety of finished composite

thicknesses.















- Counter & working electrode consisted of carbon cloth graphitized Spun Yarn Carbon Fabrics
- 500 μm threads consisting of a bundle of 10 μm fibres. Allows for flexible substrates.















- Potentials were against a Ag/AgCl reference electrode 500 μm silver wire chloridised in FeCl₃.
- Single threads were soaked in a IL / Ferrocene / GOx enzyme solution.













• The electrochemical mechanism for glucose detection in a Ferrocene mediated system^[18]:


$$GOx\text{-}FAD^+ + Glucose \rightarrow GOx\text{-}FADH_2 + Gluconolactone$$

 $2Fe^{+3} + GOx\text{-}FADH_2 \rightarrow 2Fe^{+2} + GOx\text{-}FAD^+$
 $2Fe^{+2} \rightarrow 2Fe^{+3} + 2e^-$ @ electrode surface









CV of Glucose additions to $[P_{6,6,6,14}][dca]/Ferrocene/Gox$ on carbon cloth. Scan rate 0.01 V/S



• Using the Anson equation, the calculated working area was approx 0.138 cm².

$$Q = \frac{2nFAC_{o}D_{o}^{\frac{1}{2}}}{\pi^{\frac{1}{2}}}t^{\frac{1}{2}}$$

• Due to the hydrophobic nature of the cloth, $[P_{6,6,6,14}]$ [dca] was chosen as the electrolyte.






Quick summary

- Carbon cloth shows potential as a flexible working electrode.
- Can be woven into sports athletes clothing.
- Durable, flexible sensing platform.
- $[P_{6,6,6,14}][dca]$ as an electrolyte in the glucose system shows favourable limit of detection
- A flexible, wearable one shot sensor maybe produced using IL formulations





Organic Electrochemical Transistors (OECTs)








The Aim:

- To develop an enzymatic sensor based on an OECT that uses an IL as an integral part of its structure.
- The strategy involves patterning the RTIL over the active area of the OECT, and using it as a reservoir for the enzyme and the mediator.







• Important properties of the electrolyte for this device must include wetting the PEDOT : PSS film.








- Important properties of the electrolyte for this device must include wetting the PEDOT : PSS film.
- This allows the enzyme and the mediator to be patterned over the active area of the device.
- The IL should be miscible with the aqueous phase (PBS).
- Triisobutyl(methyl)phosphonium Tosylate ($[P_{1,4,4,4}][Tos]$) due to the hydrophilic nature of the cation / anion.

$$\begin{array}{c|c} CH_3 \\ \hline \\ C_4H_9 \end{array} \\ C_4H_9 \end{array} \\ \begin{array}{c|c} C_4H_9 \end{array} \\ \begin{array}{c|c} C_4H_9 \end{array} \\ \begin{array}{c|c} C_4H_9 \end{array} \\ \end{array}$$

[19] S. Y. Yang, F. Cicoira, R. Byrne, F. Benito-Lopez, D. Diamond, R. A. Owens and G. G. Malliaras, Chem. Commun., 2010, 46, 7972-797







• The transient response of the drain current of an OECT upon application of a gate voltage of 0.4 V and duration of 3 min. The drain voltage was -0.2 V.




[19] S. Y. Yang, F. Cicoira, R. Byrne, F. Benito-Lopez, D. Diamond, R. A. Owens and G. G. Malliaras, Chem. Commun., 2010, 46, 7972-7974.





• Current modulation of the OECT as a function of glucose concentration.



• Inset shows the concept of device operation, and the arrows indicate the dissolution of the RTIL carrying the enzyme and the mediator into the analyte solution.

[19] S. Y. Yang, F. Cicoira, R. Byrne, F. Benito-Lopez, D. Diamond, R. A. Owens and G. G. Malliaras, Chem. Commun., 2010, 46, 7972-7974



• The data show the characteristic decrease of drain current upon gating which has been understood on the basis of the reactions shown below

D-glucono-1,5-lactone
$$GOx^{red}$$
 Fe^+ $PEDOT^+: PSS^- + e^-$
D-glucose GOx Fe $PEDOT^+: PSS^-$

(B)
$$PEDOT^+: PSS^- + M^+ + e^- \longrightarrow PEDOT + M^+: PSS^-$$

Reactions at the gate electrode (a) and at the channel (b) of the OECT.





(A) D-glucono-1,5-lactone
$$GOx^{red}$$
 Fe^+ PEDOT+: PSS-+ e-D-glucose GOx Fe PEDOT+: PSS-

(B)
$$PEDOT^+: PSS^- + M^+ + e^- \longrightarrow PEDOT + M^+: PSS^-$$

- As glucose in the solution is oxidised, the enzyme (GOx) itself is reduced, and cycles back with the help of the Fc/ferricenium ion (Fc+) couple, which shuttles electrons to the gate electrode (A).
- For example, for 10⁻² M of glucose, this cascade of reactions causes a current of 8x10⁻⁸ A to flow to the gate electrode.
- •At the same time, cations from the solution (M+) enter the PEDOT:
 PSS channel and dedope it. (B)



Conclusions:

• Successful integration of an OECT with an IL as electrolyte.





Conclusions:

- Successful integration of an OECT with an IL as electrolyte.
- The ionic liquid was confined on the surface of the transistor using a photolithographically patterned hydrophobic monolayer.
- •The enzyme was in a dispersed state in the ionic liquid, which may prove to be a good strategy for improving long-term storage.
- Using the glucose/ glucose oxidase pair as a model, it was demonstrated the analyte detection in the 10⁻⁷ to 10⁻² M concentration range.







• Currently for applications in materials science, there is a growing interest in 'ionogels'.

• Polymers with ionic liquids integrated such that they retain their specific properties within the polymer/gel environment.





Ionogel synthesis:

Inorganic route: Oxides, Sol-Gel. [20]

Applications in catalysis & photonics.







Ionogel synthesis:

Inorganic route: Oxides, Sol-Gel. [20]

Applications in catalysis & photonics.

Organic route: Polymers, Acrylamide gels^[21]

Applications in solid state electrolytes and separations







Ionogel synthesis:

Inorganic route: Oxides, Sol-Gel. [20]

Applications in catalysis & photonics.

Organic route: Polymers, Acrylamide gels^[21]

Applications in solid state electrolytes and separations




[20] M.-A. Nouze, J. L. Bideau, P. Gaveau, S. Bellayer and A. Vioux, *Chem. Mater.*, 2006, 18, 3931-3936.
[21] T. Ueki and M. Watanabe, *Macromolecules*, 2008, 41, 3739-3749.





Ionogel synthesis:






[20] M.-A. Nouze, J. L. Bideau, P. Gaveau, S. Bellayer and A. Vioux, *Chem. Mater.*, 2006, 18, 3931-3936.
[21] T. Ueki and M. Watanabe, *Macromolecules*, 2008, 41, 3739-3749.






Ionogel synthesis: Organic route







Ionogel synthesis: Organic route







Chem Soc Rev



Cite this: DOI: 10.1039/c0cs00059k

www.rsc.org/csr

CRITICAL REVIEW

Ionogels, ionic liquid based hybrid materials†

Jean Le Bideau, Lydie Viaub and André Vioux*b

Received 30th July 2010 DOI: 10.1039/c0cs00059k

An excellent review by Le Bideau et. al. [22]





[22] J. Le Bideau, L. Viau and A. Vioux, Chem. Soc. Rev., 2011, 40, 907-925.





Actuation










Actuation








Sensing

Characteristics:


- lonogel/dyes
- Image data analysis
- Absorbent = passive pump
- Electronics is not required









Sensing





Hue

"the degree to which a stimulus can be described"







Sensing




Visiting Berkley Oct 2011






• Incorporate printable formulations onto OECTs for biosensing




1-Ethyl-3-methylimidazolium (EMIM) cation ethyl sulfate (EtSO₄) anion

poly(*N*-isopropylacrylamide-co-*N*,*N*'-methylenebisacrylamide)





Flexible Wearable Transistor



Printing Ionogel



150 um thickness





Advantages of lonogels

• Control the Ratio of cross linker to IL.





Advantages of lonogels

- Control the Ratio of cross linker to IL.
- Less crosslinker, less dense polymer. Diffusion is improved
- Catalytically active proteins and enzymes may also be confined.
- It is therefore proposed that having "Ionogels" is a particularly attractive strategy in the field of biosensing.
- These materials, in theory, will inherit all of the favourable IL properties whilst being in a solid, semi-solid gel like structure.



Acknowledgments



Wearable Sensors	IL / Transistor work
------------------	----------------------

Dr Shirley Coyle Dion Khodagholy

Dr Ben Schazmann Prof George Malliaras

Vincenzo F. Curto Prof Róisín Owens

Caroline Barry Prof Dermot Diamond

Dr Susan Warren Dr Fernando Benito-Lopez

Dr Eithne Dempsey Dr Robert Byrne

Prof Douglas MacFarlane

Prof Dermot Diamond



Acknowledgments







CLARITY Centre & Ecosystem








SOCIAL/AGENCY

COLLABORATORS

DCU

Thanks for your attention







Presentation available for download (@Cyrusmekon)

