

Exploring The Behavior Of *In-Situ* Polymerised Ionogel Thermal Actuators

Simon Gallagher^a, Andrew Kavanagh^a, Larisa Florea^a, Katya Izgorodina^b, Kevin Fraser^a, Douglas MacFarlane^b, Dermot Diamond^a.

^a CLARITY, National Centre for Sensor Research Dublin City University, Glasnevin, Dublin 9, Ireland

^b School of Chemistry, Monash University, Wellington Rd, Clayton, 3800, Australia.

INTRODUCTION


- Poly-(N-isopropylacrylamide) (pNIPAM) is a thermo responsive polymer gel that displays an inverse solubility of aqueous solutions upon heating above its Lower Critical Solution Temperature (LCST).
- Below the LCST, the gel becomes solvated by water molecules through hydration of aliphatic groups and hydrogen bonding with the amide group.
- Above the LCST (31 – 32 °C)¹, the gel collapses along the polymer backbone before water molecules are expelled. This process is driven by the conversion from polymer-solvent bonds to polymer-polymer and solvent-solvent bonding.²
- Ionic liquids (ILs) / ionogels have evolved as a new type of material for actuators, mainly due to their unique and tunable physical properties.^[1]

AIMS

- To investigate the physicochemical interactions that occur between A) IL B) Water C) Polymer as a result in a change in temperature .
- Examine the macro actuator effect as a result of these interactions

EXPERIMENTAL

- ILs of interest in this study are; 1-ethyl-3-methylimidazolium ethyl sulfate $[C_2mIm][EtSO_4]$ and 1-ethyl-3-methylimidazolium bis(trifluoromethanesulfonylimide) $[C_2mIm][NTf_2]$ (Figure 1).



Poly(N-isopropylacrylamide)-co-N,N'-methylenebisacrylamide




Fig 1: Ionic Liquids of interest and repeating unit of the polymer.

- The thermo-physical properties of these pure water-saturated ILs were investigated using density, viscometry, and rheometry.
- All measurements were performed in temperature range corresponding above and below the LCST (20 – 35 °C).
- Storage modulus was measured using an Anton-Paar MC301 rheometer, where the temperature was ramped 5 °C / min above and below the LCST of the ionogel.
- Hydrated gels were gold sputtered using a Polaron® SC7640 Auto/Manual High Resolution Sputter coater, and SEM measurements were performed on a ZEISS® microscope instrument.

RESULTS AND DISCUSSION


- Swelling and contracting properties of the ionogel were found to differ depending on the variation and hydrophobicity of the anion.

References

1. Benito-Lopez, Fernando and Byrne, Robert and Raduta, Ana Maria and Vrana, Nihal Engin and McGuinness Garrett and Diamond Dermot (2010) Lab on a Chip, 10 (2). pp. 195-201.
2. H.G Shild, Prog. Polym. Sci., Vol. 17, 163-249, 1992

RHEOMETRY

- Storage modulus, measuring the elastic energy of the hydrated gel.



- Clear difference observed between the storage modulus of $[C_2mIm][EtSO_4]$ and $[C_2mIm][NTf_2]$ ionogels when passed through the LCST threshold.
- At the phase transition, when the polymer backbone of pNIPAM collapses and expels water, the hydrophilic $[C_2mIm][EtSO_4]$ leaves with the expelled water, producing a more compact, condensed and stiffer gel.

ACTUATION


- Actuation properties of ionogel are found to differ according to anion hydrophilicity.

IL	LCST (°C)	Diameter (mm)	Hydration diameter mm (% change)	Contraction diameter mm (% change)
$[C_2mIm][EtSO_4]$	24	12.00	15.7 (30.42)	11.2 (28.47)
$[C_2mIm][NTf_2]$	24	12.00	13.8 (15.83)	11.8 (13.67)

- Viscosity values measured were found to correlate with previous actuation measurements.

IL	IL viscosity 20 °C m.Pas	Viscosity of IL/Water below LCST m.Pas (% change)	Viscosity of IL / Water above LCST m.Pas (% change)
$[C_2mIm][EtSO_4]$	93.60	3.43 (96.33)	2.42 (97.40)
$[C_2mIm][NTf_2]$	32.49	23.93 (26.34)	12.78 (60.60)

SEM



$[C_2mIm][NTf_2]$
Shows polymer networks only in the hydrated phase (a & b)

$[C_2mIm][EtSO_4]$ display distinct porous morphology in both states (c) dry and hydrated (d) states. It shows the hydrophobicity of the anion has effect on the formation of the polymer network.

CONCLUSIONS

- The storage modulus of the ionogels are found to change significantly according to the hydrophobicity of the anion.
- The actuation properties of the ionogels correlate with the trend of viscosity values of the ILs when saturated with water.
- SEM images clearly display differences between ionogels when dry and when submerged in water.
- It is clear that the nature of the IL employed dictates the actuation properties of the ionogel.

Funding Acknowledgement

S.G., F. B. L., and D. D. acknowledge funding from Science Foundation Ireland (SFI) under the CLARITY CSET award (Grant 07/CE11147). K.J.F. acknowledges the Macro-Course Action International Re-integration Grant (IRG) (IPRG07-GA-2010-268365) and Irish Research Council for Science, Engineering and Technology.